



Instructions:

- 1) Set timer scale by turning the small screw in lower left corner of the timer.
- 2) Set "OFF" Time interval by turning small screw in the upper right corner of the timer (i.e.: sec, min, hrs).
- 3) Set "ON" time interval by turning the small screw in the lower right corner of the timer (i.e. sec, min, hrs).
- 4) Set "OFF" time by turning the outer dial of the timer, until the green arrow is at the desired "OFF" time.
- 5) Set "ON" time by turning the inner dial of the timer, until the red arrow is at the desired "ON" time.